

DRAFT

Maintenance Effort Remains Consistent with the Prior Fiscal Year

**STATEMENT OF WORK
FOR THE
STANDARDIZED
BARE BASE
LAUNDRY FACILITY
NSN 3510-01-165-6845
Inspect Repair Only As Necessary
(IROAN)**

TABLE OF CONTENTS

PARAGRAPH	PAGE
1.0 SCOPE	1
1.1 Background	1
2.0 APPLICABLE DOCUMENTS	1
2.1 Military Specifications	1
2.2 Military Standards	1
2.3 Other Government Documents and Publications	2
2.4 Industry Standards	2
3.0 REQUIREMENTS	3
3.1 General Tasks	3
3.2 Detail Tasks	3
3.2.1 Phase I - Pre-Induction	3
3.2.2 Phase II -IROAN	3
3.2.3 Phase III - Inspection, Testing and Acceptance	5
3.2.4 Phase IV - Packaging, Handling, Storage, and Transportation (PHS&T)	5
3.3 Configuration Management	6
3.3.1 Configuration Status Accounting (CSA)	6
3.3.2 Configuration Control	6
3.4 Quality Assurance Provisions	6
3.5 Government Furnished Equipment /Government Furnished Materiel	7
3.6 Contractor Furnished Materiel (CFM)	7
3.7 Acceptance	7
3.8 Rejection	7
4.0 REPORTS	7
4.1 Repairable Item Inspection Report	7
4.2 Monthly Progress Reports	8
4.3 Pre-Induction Checklist	8
Appendix A - Pre-Induction Checklist	A-1
Appendix B - List of Defective Parts and Assemblies	B-1
Appendix C - List of Repair Parts and Assemblies Required for Repairs	C-1

**STATEMENT OF WORK FOR THE
STANDARDIZED BARE BASE LAUNDRY FACILITY
Inspect Repair Only As Necessary (IROAN)
NSN 3510-01-165-6845**

1.0 SCOPE. This Statement of Work (SOW) establishes and sets forth tasks and identifies the work efforts that shall be performed by the Contractor in the IROAN effort of the Standardized Bare Base Laundry Facility, hereafter referred to as the Laundry Unit. This document contains requirements to restore the Laundry Unit to Condition Code "A." Condition Code A is defined as "serviceable/issuable without qualification, new, used, repaired or reconditioned materiel which is serviceable and issuable to all customers without limitation or restriction, including materiel with more than six months shelf-life remaining." National Stock Number (NSN) 3510-01-165-6845 shall be known as the Laundry Unit, Bare Base.

1.1 Background. IROAN is defined as "That maintenance technique which determines the minimum repairs necessary to restore equipment components or assemblies to prescribed maintenance serviceability standards by utilizing all available diagnostic equipment and test procedures in order to minimize disassembly and parts replacement."

2.0 APPLICABLE DOCUMENTS. The following documents form a part of this SOW to the extent specified. Unless otherwise specified, the issues of these documents are those listed in the Department of Defense Index of Specifications and Standards (DoDISS) and supplement thereto which is in effect on the date of solicitation. In the event of conflict between the documents referenced herein and the contents of this SOW, the contents of this SOW shall be the superseding requirement.

2.1 Military Specifications

MIL-C-46168	Coating, Aliphatic Polyurethane, Chemical Agent Resistant
MIL-C-53039	Coating, Aliphatic Polyurethane, Single Component, Chemical Agent Resistant

2.2 Military Standards

MIL-STD-129	DoD Standard Practice for Military Marking
MIL-STD-130	Identification Marking of US. Military Property
MIL-STD-461	Requirements for the Control of Electromagnetic Interference Characteristics of Subsystems and Equipment
MIL-STD-2073-1D	DoD Standard Practice for Military Packaging

2.3 Other Government Documents and Publications

DOD 4160.21-M-1	Defense Demilitarization Manual
DOD 4000.25-1-M	MILSTRIP Manual
SL-3-09950A	Field Laundry Unit
TM 09950A-14/1 M/S	Laundry Facility, Std Bare Base
TM 09950A-14/1 M/S, CH00A	Laundry Facility, Std Bare Base
TM 09950A-14/1 M/S, Supplement 1	Laundry Facility, Std Bare Base
TM 3080-12	Corrosion Prevention and Control for Marine Corps Equipment
TM 3080-50	Corrosion Control Procedures Depot Maintenance Activities for Marine Corps Equipment
TM 4700-15/1H	Ground Equipment Record Procedures
TM 4750-15/1	Painting and Registration Marking for Marine Corps Combat and Tactical Equipment
TM 4750-15/2	Camouflage Paint Patterns

Military Handbooks (For Guidance)

MIL-HDBK-61	Configuration Management Guidance
-------------	-----------------------------------

2.4 Industry Standards

ANSI/ISO/ASQC Q9002-1994	Quality Systems-Model for Quality Assurance in Production, Installation, and Servicing
--------------------------	--

Industry Standards (For Guidance)

ANSI/EIA-649	National Consensus Standard for Configuration Management
--------------	--

Copies of Military Specifications and Standards are available from the DOD Single Stock Point, Document Automation and Production Service, Building 4/D, 700 Robbins Avenue, Philadelphia, PA 19111-5094, Telephone (215) 697-2179 or DSN 442-2179, or <http://www.dodssp.daps.mil>. Copies of other government documents and publications required

by contractors in connection with specific SOW requirements shall be obtained through the Contracting Officer: Contracts Department (Code 891), P.O. Drawer 43019, 814 Radford Blvd., Albany, Georgia 31704-3019, commercial telephone number (229) 639-6753 or DSN 567-6753. Copies of engineering drawings, if applicable, shall be obtained from Supply Chain Management Center, Attn: Code 583-1, 814 Radford Blvd STE 20320, Albany, Georgia 31704-0320, commercial telephone number (229) 639-6410 or DSN 567-6410.

3.0 REQUIREMENTS

3.1 General Tasks. In fulfilling the specified requirements, the Contractor shall:

a. Provide materials, labor, facilities, missing parts, and repair parts necessary to inspect, diagnose, restore, and test the Laundry Unit. Upon completion of IROAN, repaired equipment shall be Condition Code "A".

b. Provide all tools and test equipment required to test, inspect, repair, and calibrate the Laundry Unit.

c. Conduct in-process and final on-site testing for witness by a Marine Corps Systems Command (MCSC) (Code CSLE), Albany, Georgia, representative.

d. Be responsible for all structural, electrical and mechanical requirements associated with the restoration of the Laundry Unit.

3.2 Detail Tasks. The following tasks describe the different phases for IROAN of the Laundry Unit.

3.2.1 Phase I - Pre-Induction. The Contractor shall perform a pre-induction inspection analysis for each Laundry Unit using the Contractor's diagnosis, inspection and testing techniques to determine extent of work and parts required. This inspection shall include all items associated with the Laundry Unit as found in TM 09950A-14/1 M/S, TM 09950A-14/1 M/S CH00A, TM 09950A 14/1 M/S Supplement 1 and SL-3-09950A. These findings shall be annotated on a Pre-Induction Checklist (Appendix A) and shall be provided to the government in accordance with Paragraph 4.0 of this SOW.

3.2.2 Phase II - IROAN. After pre-induction tests and inspections have been completed, repair of the Laundry Unit shall be accomplished in accordance with this SOW. Deficiencies noted on the Pre-Induction Checklist during Phase I shall be repaired/replaced. Components or assemblies shall not be disassembled for replacement of mandatory parts unless that part has failed, or the component assembly wherein the part is located is disassembled for repair.

a. Pre-Induction Checklist - Information recorded on the Pre-Induction Checklist report shall be used as a guide to repair the Laundry Unit system in accordance with this SOW.

b. Technical Instruction (TI) - All TI's not previously applied to the Laundry Unit shall be applied during the IROAN and shall be annotated on Equipment Record Jacket in accordance with TM 4700-15/1H.

c. Corrosion - For corrosion prevention and treatment use TM 3080-12 and TM 3080-50.

d. Fluid Leaks - The following shall be used as a guide in determining degree of fluid loss:

(1) Class I - Seepage of fluid (as indicated by wetness or discoloration) not great enough to form drops.

(2) Class II - Leakage of fluid great enough to form drops, but not enough to cause drops to fall from the item being checked/inspected.

(3) Class III- Leakage of fluid great enough to form drops that fall from the item being checked/inspected.

NOTE:

A Class I Leak, except in fuel or brake systems, is an acceptable condition at any time and does not require corrective action.

e. Belts - Replace all.

f. Data Plates - All required data plates and decals shall be in place and shall be legible. Each repaired Laundry Unit shall have an IROAN data plate affixed to the main unit in close proximity to the existing data plate. The data plate shall meet the requirements of MIL-STD-130 and TM 4750-15/2.

g. Painting/Coating (Exterior/Interior) - If painting/coating is required, refer to TM 4750-15/1 and TM 4750-15/2. The Laundry Unit shall be cleaned in accordance with TM 3080-50, Chapter 4, and coated with Aliphatic Polyurethane Coating, in accordance with MIL-C-46168 or MIL-C-53039.

h. Demilitarization - All end items that are identified as non-repairable and require demilitarization codes, shall be reported to the MCSC (Code CSLE), Albany, Georgia, representatives, who will provide disposition instructions in accordance with DOD 4160.21-M-1.

i. Electromagnetic Emission - All requirements pertaining to control of electromagnetic interference, emission and susceptibility shall be in accordance with MIL-STD-461.

j. Hardware

(1) Replace broken, unserviceable and/or missing hardware including nuts, bolts, screws, washers, turnlock fasteners, mandatory replacement items, safety and one-time use items, etc., in

accordance with TM 09950A-14/1 M/S and SL-3-09950A. Unserviceable would include any of the above that failed to function properly.

(2) Ensure proper hardware locking devices are present and operational on all moving mechanical assemblies.

(3) Hardware normally supplied with commercial parts shall be used unless specifically prohibited.

k. Hoses - All hoses and fittings shall be visually inspected for damage or deterioration. Any hose showing signs of leakage, kinking or separation of outer coating shall be replaced. This inspection shall be performed during the Pre-induction inspection of the Laundry Unit.

l. Cable Assemblies - All cables and cable connections shall be tested and visually inspected for damage or corrosion. Any cable or cable connector showing signs of damage, corrosion or separation of outer coating shall be repaired/replaced and tested with its respective component/assembly to assure satisfactory compliance with all operational tests.

m. Filters - Replace all.

3.2.3 Phase III - Inspection, Testing and Acceptance

a. Inspection, Testing and Acceptance of the Laundry Unit shall be conducted in accordance with TM 09950A-14/1 M/S.

b. The Contractor shall be responsible for conducting required tests and shall ensure all necessary personnel are available to complete the final acceptance. Acceptance tests shall be held at the Contractor's facility. MCSC (Code CSLE), Albany, Georgia, representatives shall be given a minimum of two weeks notice prior to beginning acceptance testing. The test area shall be cleared of all equipment parts, components, etc., not required for the test.

c. The Contractor shall be responsible for correcting any deficiencies identified during inspection/testing. MCSC (Code CSLE), Albany, Georgia, representatives may require the Contractor to repeat tests or portions thereof, if the original tests fail to demonstrate compliance with this SOW.

d. Acceptance testing on all Laundry Units repaired under the provisions of this SOW shall be accomplished in accordance with TM 09950A-14/1 M/S. Operational Tests are to be conducted on each Laundry Unit upon completion of repairs and prior to the equipment being returned to stock, to insure the unit will perform as required.

3.2.4 Phase IV - Packaging, Handling, Storage and Transportation (PHS&T).

a. The contractor shall be responsible for the preservation and packaging of items being repaired under the terms of this statement of work. Items scheduled for long-term storage or

shipment to overseas destinations shall be in accordance with the Level "A" requirements of MIL-STD-2073-1D, Method 10. Items being scheduled for domestic shipment, immediate use or short-term storage shall be to Level "B" requirements.

b. Marking for shipment and storage shall be in accordance with MIL-STD-129.

c. The Marine Corps will provide the contractor with the shipping address(es) for delivery of the repaired equipment. The contractor shall be responsible for arranging for shipment to the pre-designated site(s). The Marine Corps will be responsible for the transportation costs associated with shipping the subject equipment to and from the Contractor.

3.3 Configuration Management

3.3.1 Configuration Status Accounting (CSA).

a. The Contractor shall record and submit data on retrofit accomplished during Phase II. Any approved Modification Instructions (MIs) or Engineering Change Proposals (ECP's) not previously applied shall be applied during Phase II of the IROAN process.

b. The Contractor shall determine the application status of approved configuration changes by visual inspections to the extent possible. The government will identify the configuration changes to be inspected by furnishing a Configuration Inspection Checklist to the Contractor. The Contractor shall use one checklist per Laundry Unit to record their inspection findings along with other required data.

c. The Contractor shall record serial numbers of the assemblies listed on the Configuration Inspection Checklist. The Contractor shall record the information on the same form that was used to record the application status of configuration changes.

3.3.2 Configuration Control. The contractor shall apply configuration control procedures to established configuration items. The contractor shall not implement configuration changes to an item's documented performance or design characteristics without prior written authorization. If it is necessary to temporarily depart from the authorized configuration, the contractor shall prepare and submit a Request For Deviation. MIL-HDBK-61 and ANSI/EIA-649 provide guidance for preparing this configuration control document.

3.4 Quality Assurance Provisions. The Contractor shall provide and maintain a Quality System that as a minimum, adheres to the requirements of ANSI/ISO/ASQC Q9002-1994, Quality Systems - Model for Quality Assurance in Production, Installation, and Servicing. The program shall ensure quality throughout all areas to include processing, assembly, inspection, test, maintenance, and preparation for delivery and shipping. Unless otherwise specified in the contract, the Contractor shall be responsible for performance of all inspection requirements. The Government, MCSC (Code CSLE), Albany, Georgia, reserves the right to perform any of the inspections set forth in the contract where such inspections are deemed necessary to assure

products and services conform to the prescribed requirements. The Contractor shall provide an Inspection and Test Plan.

3.5 Government Furnished Equipment (GFE)/Government Furnished Materiel (GFM). The Management Control Activity (MCA/Code 573-2) will coordinate Government Furnished Equipment/Government Furnished Materiel (GFE)/(GFM) requests and maintain a central control system on all government owned assets in the contractor's possession. The MCA will forward a GFE Accountability Agreement to the contractor for signature on an annual basis to establish a chain of custody and identify property responsibilities for Marine Corps assets. The contractor is to acknowledge receipt of GFM to the MCA within 15 days of receipt. (This can be done by mailing (Materiel Management Department, Management Control Activity (Code 573-2) 814 Radford Blvd, STE 20320, Albany, GA 31704-0320) or faxing (commercial 229-639-5498 or DSN 567-5498) a copy of the DD1348).

3.6 Contractor Furnished Materiel (CFM). The contractor may requisition materiel as required in the performance of the SOW through the DoD Supply System. DoD 4000.25-1-M (MILSTRIP) Chapter 11 provides guidance to contractors on the requisitioning process. The contractor's decision to utilize CFM procured from the DoD Supply System shall be based upon cost effectiveness, availability of materiel and the required completion/delivery date.

3.7 Acceptance. The performance of the Contractor and the quality of work delivered, including all equipment furnished and documentation written or compiled, shall be subject to in-process review and inspection during performance. Inspection may be accomplished in-plant or at any work site or location, and MCSC (Code CSLE), Albany, Georgia, representatives shall be permitted to observe the work or to conduct inspection at all reasonable hours. Final inspection and acceptance testing shall be conducted at the Contractor's facility. Final acceptance shall be conducted on 100 percent of items to verify that the units meet all requirements.

3.8 Rejection. Failure to comply with any of the specified requirements listed herein shall be reason for rejection by MCSC (Code CSLE), Albany, representative. The Contractor shall, at no additional cost to MCSC, Albany, Georgia, provide the following:

a. Develop an approach for modification or correction of all deficiencies.

b. Upon approval of a documented approach, the Contractor shall correct the deficiencies and repeat the verification until an acceptable compliance with acceptance test procedures is demonstrated.

4.0 REPORTS. All report deliverables shall be submitted in hard copy to Commander (Code CSLE), Marine Corps Systems Command, 814 Radford Blvd., Suite 20343, Albany, Georgia 31704-0343, unless directed other wise in a Contract Data Requirements List.

4.1 Repairable Item Inspection Report. The Contractor shall provide a Repairable Item Inspection Report for each Laundry Unit. The report shall be identified by United States Marine Corps Serial Number.

4.2 Monthly Progress Reports. The Contractor shall provide Monthly Progress Reports summarizing the progress and status of the IROAN Program.

4.3 Pre-Induction Checklist. The Contractor shall complete the Pre-Induction Inspection Checklist for each Laundry Unit repaired. These documents shall be available during final acceptance testing. One copy of each document shall be provided to MCSC, Albany, Georgia, Code CSLE, after final acceptance of the Laundry Unit.

a. The inspection checklist shall contain, but not be limited to the following:

- (1) Laundry Unit serial number. Appendix A**
- (2) Condition Code of Laundry Unit at receipt. Appendix A**
- (3) Results of operational test. Appendix A**
- (4) List of defective parts and assemblies. Appendix B**
- (5) List of repair parts and assemblies required for repairs. Appendix C**
- (6) Corrosion prevention methods that shall be used. Appendix A**

COMPONENTS

PASS FAIL REMARKS

Serial number: _____ **Condition Code at receipt:** _____

Results of operational test:

List of defective parts and assemblies. Appendix B

List of repair parts and assemblies required for repairs. Appendix C

Corrosion prevention methods that shall be used.

Inspect all components for operating/malfunction/defective parts per TM 09950A-14/1 M/S.
Visually check components for leaks, damage, loose parts & hardware. No disassembly of
components is allowed unless the component is determined to be defective.

COMPONENTS	PASS	FAIL	REMARKS
LAUNDRY FACILITY BARE BASE	_____	_____	_____
MAIN PLATFORM ASSEMBLY, (SEE FIGURE 7-2)	_____	_____	_____
STORAGE BIN ASSEMBLY, (SEE FIGURE 7-3)	_____	_____	_____
LAUNDRY WASHER ASSEMBLY, (SEE FIGURE 7-4)	_____	_____	_____
LAUNDRY WASHER ASSEMBLY, (SEE FIGURE 7-7)	_____	_____	_____
CLAMP ASSEMBLY, (SEE FIGURE 7-13)	_____	_____	_____
COUPLINGS	_____	_____	_____
COUPLING HALF, QUICK DISCONNECT,	_____	_____	_____
CAM-LOCKING ALL ENDS	_____	_____	_____
PLUG, SQ HD,	_____	_____	_____
ELBOW, ST BRASS	_____	_____	_____
BUSHING, BRASS,	_____	_____	_____
COMPRESSOR UNIT,	_____	_____	_____
RECIPROCATING, (SEE FIGURE 7-14)	_____	_____	_____
CONTROLLER AND	_____	_____	_____

COMPONENTS

PASS FAIL REMARKS

ELECTRICAL PANEL,
(SEE FIGURE 7-16)
WATER HEATER,
(SEE FIGURE 7-22)
HEATER FUEL LINE ASSEMBLY,
(SEE FIGURE 7-23)
HEATER TIEDOWN ASSEMBLY,
(SEE FIGURE 7-24)
LAUNDRY EXTRACTOR,
(SEE FIGURE 7-25)
TIE DOWN CLIP ASSEMBLY,
(SEE FIGURE 7-30)
WATER PUMP ASSEMBLY,
(SEE FIGURE 7-31)
HOSE CONNECT ASSEMBLY,
(SEE FIGURE 7-32)
PUMP TIEDOWN ASSEMBLY,
(SEE FIGURE 7-33)
DRYER ASSEMBLY,
(SEE FIGURE 7-34)
DRYER FUEL LINE ASSEMBLY,
(SEE FIGURE 7-23)
EXHAUST HOSE
TIEDOWN ASSEMBLY,
(SEE FIGURE 7-45)
EXHAUST HOSE
TIEDOWN ASSEMBLY,
(SEE, FIGURE 7-46)
CONDUIT ASSEMBLY,
(SEE FIGURE 7-47)
RAIL, SIDE, 84 IN LG
CLOTHES BIN ASSEMBLY,
(SEE, FIGURE 7-48)
POWER CABLE ASSEMBLY,
(SEE FIGURE, 7-49)
SPACER
COVER ASSEMBLY RED 1, 2, & 3
MAIN PLATFORM ASSEMBLY
PLATFORM, LEFT ASSEMBLY
PLATFORM, FRAME ASSEMBLY
DECK, LARGE TOP ASSEMBLY
DECK, SMALL TOP ASSEMBLY
DECK, LARGE BOTTOM
ASSEMBLY
DECK, SMALL BOTTOM
ASSEMBLY
RAIL
RAIL, SIDE
SLEEVE
STRAP, RETAINING,

COMPONENTS	PASS	FAIL	REMARKS
PLATFORM, RIGHT ASSEMBLY	_____	_____	_____
JOINING PANEL ASSEMBLY	_____	_____	_____
STORAGE BIN ASSEMBLY	_____	_____	_____
BIN, LARGE	_____	_____	_____
PLATFORM	_____	_____	_____
BIN, SMALL	_____	_____	_____
COVER ASSEMBLY	_____	_____	_____
FASTENER, LINK LOCK	_____	_____	_____
TRAY	_____	_____	_____
LAUNDRY WASHER	_____	_____	_____
WASHER ASSEMBLY,	_____	_____	_____
(SEE FIGURE 7-5)	_____	_____	_____
PLATE, TANK MOUNTING	_____	_____	_____
ELBOW, PIPE,	_____	_____	_____
TEE, PIPE, STL,	_____	_____	_____
COCK, DRAIN,	_____	_____	_____
WASHER ASSEMBLY, OPEN END	_____	_____	_____
COVER, BASE SIDE LEFT	_____	_____	_____
COVER, BASE FRONT	_____	_____	_____
COVER, BASE SIDE RIGHT	_____	_____	_____
SUPPLY INJECTOR ASSEMBLY	_____	_____	_____
SHELL ASSEMBLY	_____	_____	_____
SHELL FRONT ASSEMBLY	_____	_____	_____
SHELL, EXTRUSION	_____	_____	_____
RING, SHELL	_____	_____	_____
PLATE, MOUNTING	_____	_____	_____
MICROSWITCH	_____	_____	_____
CAM, DOOR	_____	_____	_____
HANDLE ASSEMBLY,	_____	_____	_____
DOOR, ASSEMBLY	_____	_____	_____
BRACKET, HINGE	_____	_____	_____
CYLINDER ASSEMBLY	_____	_____	_____
HOUSING, SHAFT SEAL	_____	_____	_____
GASKET, SHAFT SEAL	_____	_____	_____
SEAL, PLAIN, STL,	_____	_____	_____
COVER, SHAFT RETAINER	_____	_____	_____
SPACER, SHAFT RETAINER	_____	_____	_____
KEY, MACHINE, STL	_____	_____	_____
SPIDER,	_____	_____	_____
GEAR ASSEMBLY,	_____	_____	_____
SPEED DECREASER	_____	_____	_____
MOTOR, ALTERNATING	_____	_____	_____
MOUNT, MOTOR	_____	_____	_____
BRACKET, MOTOR MOUNT, LEFT	_____	_____	_____
BRACKET, MOTOR MOUNT, RIGHT	_____	_____	_____
BELT GUARD ASSEMBLY	_____	_____	_____
BRACKET, BELT UPPER	_____	_____	_____
BELT, V, RBR,	_____	_____	_____
BRACKET, BELT, LOWER LEFT	_____	_____	_____
PULLEY, GROOVE,	_____	_____	_____
BUSHING, SLEEVE	_____	_____	_____

COMPONENTS	PASS	FAIL	REMARKS
V-PULLEY	---	---	_____
BUSHING, SLEEVE	---	---	_____
COVER, SYPHON	---	---	_____
BREAKER	---	---	_____
PIPE, ELBOW	---	---	_____
WATER LEVEL FLOAT,	---	---	_____
CHAMBER ASSEMBLY,	---	---	_____
(SEE FIGURE 7-6)	---	---	_____
SOAP CHUTE	---	---	_____
COVER, SOAP CHUTE	---	---	_____
HINGE, SOAP CHUTE	---	---	_____
ROD, SOAP CHUTE	---	---	_____
PIPE, METALLIC	---	---	_____
HOSE, NONMETALLIC,	---	---	_____
PIPE, WATER INLET	---	---	_____
VALVE, ANGLE,	---	---	_____
WATER LEVEL FLOAT	---	---	_____
CHAMBER ASSEMBLY	---	---	_____
SWITCH, LIQUID LEVEL	---	---	_____
TUBING, GLASS,	---	---	_____
CLAMP, LOOP	---	---	_____
BRACKET, LEVEL CONTROL	---	---	_____
BRACKET, TOP FLOAT	---	---	_____
CHAMBER	---	---	_____
BRACKET, BOTTOM	---	---	_____
FLOAT CHAMBER	---	---	_____
FLOAT ASSEMBLY,	---	---	_____
LIQUID LEVEL	---	---	_____
FLOAT	---	---	_____
ROD, FLOAT,	---	---	_____
SPFED NUT	---	---	_____
LAUNDRY WASHER ASSEMBLY	---	---	_____
FRAME ASSEMBLY	---	---	_____
DOOR ASSEMBLY,	---	---	_____
(SEE FIGURE 7-8)	---	---	_____
DOOR LOCK ASSEMBLY,	---	---	_____
(SEE FIGURE 7-9)	---	---	_____
DRAW BAND, WASHER	---	---	_____
EXTRACTOR	---	---	_____
GASKET, RBR CHLOROPRENE	---	---	_____
DRUM FRONT	---	---	_____
CYLINDER ASSEMBLY	---	---	_____
SPIDER AND SHAFT ASSEMBLY	---	---	_____
ROD, THREADED END	---	---	_____
RING, GASKET CLAMP	---	---	_____
GASKET, SOCK	---	---	_____
MOTOR	---	---	_____
PLATE, MOTOR MOUNTING	---	---	_____
ROD, MOTOR ADJUSTING	---	---	_____
BELT	---	---	_____
PULLEY, GROOVE,	---	---	_____

COMPONENTS	PASS	FAIL	REMARKS
BUSHING, SHEAVE	_____	_____	_____
DRUM ASSEMBLY	_____	_____	_____
WATER INLET ASSEMBLY,	_____	_____	_____
(SEE FIGURE 7-10)	_____	_____	_____
SHEAVE	_____	_____	_____
BUSHING, SHEAVE	_____	_____	_____
GEAR ASSEMBLY,	_____	_____	_____
PLATE, MOUNTING	_____	_____	_____
SEAL AND CARRIAGE ASSEMBLY,	_____	_____	_____
SEAL, PLAIN	_____	_____	_____
DISPENSER ASSEMBLY,	_____	_____	_____
(SEE FIGURE 7-11)	_____	_____	_____
GAUGE, TEMPERATURE	_____	_____	_____
BOTTLE, SUPPLY	_____	_____	_____
VALVE ASSEMBLY, DRAIN,	_____	_____	_____
(SEE FIGURE 7-12)	_____	_____	_____
PLUG, PIPE	_____	_____	_____
HOSE, DRAIN	_____	_____	_____
DOOR ASSEMBLY	_____	_____	_____
DOOR HINGE AND	_____	_____	_____
HANDLE	_____	_____	_____
BASE, DOOR HINGE	_____	_____	_____
BUSHING, FLANGE,	_____	_____	_____
PIN, DOOR HINGE	_____	_____	_____
BEARING, WASHER,	_____	_____	_____
BAR, DOOR	_____	_____	_____
FASTENER, PAWL	_____	_____	_____
BOLT, PIVOT	_____	_____	_____
BUSHING, SLEEVE	_____	_____	_____
RING, RETAINING	_____	_____	_____
WINDOW, OBSERVATION, GLASS,	_____	_____	_____
GASKET, DOOR GLASS	_____	_____	_____
FRAME, DOOR	_____	_____	_____
DRAW BAND, DOOR	_____	_____	_____
GASKET, DRAW BAND	_____	_____	_____
GASKET, DOOR	_____	_____	_____
DOOR LOCK ASSEMBLY	_____	_____	_____
DOOR LOCK COVER AND SWITCH	_____	_____	_____
COVER, DOOR LOCK	_____	_____	_____
SWITCH, PUSH	_____	_____	_____
BOOT, DUST AND MOISTURE	_____	_____	_____
SEAL	_____	_____	_____
BRACKET, MOUNTING	_____	_____	_____
BUSHING, ELECTRICAL	_____	_____	_____
CONDUCTOR,	_____	_____	_____
SOLENOID,	_____	_____	_____
SWITCH,	_____	_____	_____
PLATE, DOOR LOCK	_____	_____	_____
SPRING, DOOR LOCK	_____	_____	_____
BAR, DOOR LOCK	_____	_____	_____
SPRING, DOOR LATCH	_____	_____	_____

COMPONENTS	PASS	FAIL	REMARKS
WATER INLET ASSEMBLY	_____	_____	_____
LEVER, MANUAL CONTROL	_____	_____	_____
CLEVIS, ROD END,	_____	_____	_____
CYLINDER ASSEMBLY,	_____	_____	_____
ROD, ADJUSTINC STUD	_____	_____	_____
BRACKET, MOUNTING	_____	_____	_____
COUPLER, FEMALE	_____	_____	_____
COUPLING HALF, QUICK	_____	_____	_____
DISCONNECT,	_____	_____	_____
ELBOW, PIPE,	_____	_____	_____
NIPPLE, PIPE,	_____	_____	_____
PIPE, METALLIC,	_____	_____	_____
ELBOW, PIPE TO HOSE,	_____	_____	_____
ELBOW, PIPE,	_____	_____	_____
BUSHING, PIPE	_____	_____	_____
TEE, PIPE	_____	_____	_____
VALVE, BALL,	_____	_____	_____
NIPPLE, PIPE,	_____	_____	_____
DISPENSER ASSEMBLY	_____	_____	_____
DISPENSER	_____	_____	_____
COVER	_____	_____	_____
HOSE, SUPPLY1	_____	_____	_____
SUPPLY HOSE, AIR	_____	_____	_____
HOSE, SUPPLY 2	_____	_____	_____
HOSE, SUPPLY 3	_____	_____	_____
HOSE, SUPPLY 4	_____	_____	_____
FITTING, HOSE	_____	_____	_____
COUPLING, PIPE,	_____	_____	_____
HOSE, SUPPLY INLET	_____	_____	_____
ADAPTER, STRAIGHT	_____	_____	_____
VALVE, SOLENOID,	_____	_____	_____
MANIFOLD, SUPPLY	_____	_____	_____
BRACKET, MANIFOLD	_____	_____	_____
MOUNTING	_____	_____	_____
DRAIN VALVE ASSEMBLY	_____	_____	_____
PLATE, TOP	_____	_____	_____
BELLOWS, RUBBER,	_____	_____	_____
ADAPTER, STRAIGHT,	_____	_____	_____
PLATE, MOUNTING	_____	_____	_____
BRACKET	_____	_____	_____
HOSE, NONMETALLIC,	_____	_____	_____
PINCH TUBE	_____	_____	_____
CLAMP ASSEMBLY	_____	_____	_____
ANGLE	_____	_____	_____
ROD, THREADED, SHORT	_____	_____	_____
RING, HANGER	_____	_____	_____
AIR COMPRESSOR ASSEMBLY	_____	_____	_____
GRILLE, METAL	_____	_____	_____
HANDLE, DOOR, L STYLE	_____	_____	_____
KIT, SWITCH, (SEE FIGURE 7-15)	_____	_____	_____
HOUSING, AIR COMPRESSOR	_____	_____	_____

COMPONENTS	PASS	FAIL	REMARKS
CYLINDER, HEAD ASSEMBLY, RIGHT HAND	_____	_____	_____
CYLINDER HEAD ASSEMBLY, LEFT HAND	_____	_____	_____
MOTOR, ALTERNATING	_____	_____	_____
CABLE ASSEMBLY, PRESSURE SWITCH ASSEMBLY	_____	_____	_____
SWITCH, PRESSURE	_____	_____	_____
PLUG, BUTTON	_____	_____	_____
WIRE ASSEMBLY, BLK	_____	_____	_____
WIRE ASSEMBLY, WHT	_____	_____	_____
CONTROLLER AND ELECTRICAL PANEL SUPPORT	_____	_____	_____
FRAME ASSEMBLY	_____	_____	_____
FACE PLATE, LAUNDRY, COVER, CONTROLLER	_____	_____	_____
CONTROLLER ASSEMBLY	_____	_____	_____
HEAD ASSEMBLY, CONTROL BOX, (SEE FIGURE 7-17)	_____	_____	_____
CONTROL BOX ASSEMBLY, (SEE FIGURE 7-18)	_____	_____	_____
CONTROL CHASIS ASSEMBLY, LAUNDRY, (SEE FIGURE 7-19)	_____	_____	_____
HOSE, LOW PRESSURE	_____	_____	_____
ADAPTER, STRAIGHT SLEEVE	_____	_____	_____
FIRE EXTINGUISHER	_____	_____	_____
PLATE, MOUNTING	_____	_____	_____
STAND, CONTROLLER SUPPORT	_____	_____	_____
LOAD CENTER	_____	_____	_____
ENCLOSURE	_____	_____	_____
BRACKET, INTERIOR MOUNT	_____	_____	_____
KIT, INTERIOR TRIM	_____	_____	_____
CAP, END SEAL	_____	_____	_____
MAIN BREAKER, 30 AMP	_____	_____	_____
CIRCUIT BREAKER, 20 AMP	_____	_____	_____
BOX, 3 GANG	_____	_____	_____
GASKET, SYNTH-RBR,	_____	_____	_____
CONNECTOR, RECEPTACLE	_____	_____	_____
OUTLET	_____	_____	_____
COVER, CONDUIT	_____	_____	_____
COVER, LIFT	_____	_____	_____
SWITCH, MOTOR STARTING	_____	_____	_____
HEAD ASSEMBLY	_____	_____	_____
WINDOW, OBSERVATION,	_____	_____	_____
LATCH, SPECIAL	_____	_____	_____
LAMP, 28V	_____	_____	_____
SOCKET, LAMP	_____	_____	_____
NAME PLATE	_____	_____	_____
WARNING	_____	_____	_____

COMPONENTS

PASS FAIL REMARKS

NAME PLATE,
TUBING,
TYRAP,
BRACKET, RECEPTACLE
RECEPTACLE
ANGLE, CENTER
DOOR ASSEMBLY, PLASTIC
WET PART, LAUNDRY
PARTITION, SWITCH
SKIRT, TIMING, LAUNDRY
REAR ASSEMBLY
BACK
POWER SUPPLY
VALVE, SOLENOID,
STRAINER, SEDIMENT,
NIPPLE, PIPE,
ANGLE
PLUG, PIPE
BLOCK, MANIFOLD,
CONTROL CHASIS ASSEMBLY
CONTROL PANEL ASSEMBLY,
(SEE FIGURE 7-20)
FUSE, CARTRIDGE,
FUSEHOLDER,
VALVE, SOLENOID,
VALVE, AIR CONTROL, 3 WAY
RELAY, 3PDT, 10 AMP
SWITCH, PRESSURE
RELAY,
TIMING MOVEMENT,
MECHANICAL,
(SEE FIGURE 7-21)
CONTROL PANEL ASSEMBLY
PANEL, CONTROL
TIMER, SEQUENTIAL
SWITCH, TOGGLE,
COVER, SWITCH
REVERSING TIMER ASSEMBLY
SHAFT, SHOULDERED,
SWITCH, SENSITIVE,
ADAPTER, SWITCH
CAM, CONTROL
SETSCREW,
BRACKET, TIMER
LAUNDRY EXTRACTOR
ASSEMBLY
EXTRACTOR, BOCK MOISTRITE
AND SPEEDRY
MOTOR ASSEMBLY,
(SEE FIGURE 7-26)
MOTOR ASSEMBLY,

COMPONENTS	PASS	FAIL	REMARKS
(SEE FIGURE 7-27)			
SHEAVE, PULLEY			
V-BELT			
LID			
FRAME, LID HINCE			
BASKET BALL			
LID GASKET			
CURB ASSEMBLY			
WASHER, LEAD			
RUBBER WASHER			
HOSE,			
BASKET ASSEMBLY			
POST, CENTER			
SEAL,			
CENTER UNIT ASSEMBLY,			
(SEE FIGURE 7-28)			
HUB, BRAKE			
BACK PANEL ASSEMBLY,			
(SEE FIGURE 7,29)			
BASE ASSEMBLY			
TRUNNION FRAME, ASSEMBLY			
COUPLING HALF,			
MOTOR ASSEMBLY #1			
MOTOR, 3 HP			
SWITCH,			
MOUNT, SWITCH			
COUPLING			
HUB, BODY,			
PLATE, MOTOR MOUNT			
MOTOR ASSEMBLY #2			
MOTOR			
HUB, PULLEY			
PLATE, MOTOR MOUNT			
CENTER UNIT ASSEMBLY			
PIN, STUD			
ARM, BRAKE			
ARM, OPERATING			
BRACKET			
SPRING, HELICAL, EXTENSION			
BRAKE SHOE,			
COVER, TOP END			
SHIELD, SOLENOID			
ROD, SOLENOID			
SOLENOID, BRAKE			
HUB			
BALL, BASKET			
INSERT, NYLON			
PACKING,			
CAP, BUMPER			
BUMPER RUBBERS			
CAP, TRUNNION			

COMPONENTS	PASS	FAIL	REMARKS
RUBBER, TRUNNION	_____	_____	_____
HUB, PULLEY	_____	_____	_____
SHEAVES, PULLEY	_____	_____	_____
BACK PANEL ASSEMBLY	_____	_____	_____
BUTTON, START	_____	_____	_____
SWITCH, PUSH-PULL,	_____	_____	_____
BUTTON, RED	_____	_____	_____
LIGHT, INDICATOR	_____	_____	_____
MICROSWITCH	_____	_____	_____
SOLENOID,	_____	_____	_____
RELAY, ELECTRO MAGNETIC	_____	_____	_____
TIMER,	_____	_____	_____
FUSE HOLDER	_____	_____	_____
FUSE, CARTRIDGE,	_____	_____	_____
TERMINAL BOARD	_____	_____	_____
COVER	_____	_____	_____
PLATE, BOTTOM	_____	_____	_____
BACK AND SIDES, CONTROL	_____	_____	_____
PANEL	_____	_____	_____
PLATE, MOUNT	_____	_____	_____
PLATE, TOP	_____	_____	_____
TIE DOWN CLIP ASSEMBLY	_____	_____	_____
BAR, TIE DOWN CLIP	_____	_____	_____
LEG, TIE DOWN CLIP	_____	_____	_____
PLATFORMS	_____	_____	_____
WATER PUMP ASSEMBLY	_____	_____	_____
WATER PUMP ASSEMBLY	_____	_____	_____
FRAME, AL-ALY	_____	_____	_____
SWITCH BOX ASSEMBLY	_____	_____	_____
COVERS	_____	_____	_____
COVER, BOX, FRONT	_____	_____	_____
PUMP UNIT	_____	_____	_____
BRACKET	_____	_____	_____
MOTOR, ALTERNATING	_____	_____	_____
CAP,	_____	_____	_____
COUPLING HALF,	_____	_____	_____
NIPPLE, PIPE	_____	_____	_____
HOSE CONNECTION ASSEMBLY	_____	_____	_____
SUCTION STRAINER ASSEMBLY	_____	_____	_____
COUPLING, QUICK DISCONNECT	_____	_____	_____
SUCTION HOSE ASSEMBLY	_____	_____	_____
COUPLING, HALF	_____	_____	_____
HEATER INTAKE HOSE	_____	_____	_____
ASSEMBLY	_____	_____	_____
WASHER, INTAKE HOSE	_____	_____	_____
ASSEMBLY	_____	_____	_____
HOSES, WATER,	_____	_____	_____
CLOTHES BIN DISCHARGE HOSE	_____	_____	_____
EXTRACTOR DISCHARGE HOSE	_____	_____	_____
ASSEMBLY	_____	_____	_____
PUMP TIE DOWN ASSEMBLY	_____	_____	_____

COMPONENTS	PASS	FAIL	REMARKS
CATCH, FIXED ASSEMBLY	—	—	—
CATCH, ADJUSTABLE	—	—	—
PLATFORM ASSEMBLY	—	—	—
DRYER ASSEMBLY	—	—	—
BLOWER ASSEMBLY,	—	—	—
(SEE FIGURE 7-35)	—	—	—
HOSE ASSEMBLIES	—	—	—
BURNER TUMBLER ASSEMBLY,	—	—	—
(SEE FIGURE 7-36)	—	—	—
SWITCHES, SENSITIVE	—	—	—
COVER	—	—	—
LIGHT, INDICATOR,	—	—	—
ALARM, BUZZER	—	—	—
BUZZER,	—	—	—
DOOR ASSEMBLY	—	—	—
CHAIN, WELDLESS	—	—	—
TIMER, SEQUENTIAL	—	—	—
PLATE, INDENT	—	—	—
LABEL, CAUTION	—	—	—
LABEL, WARNING	—	—	—
ARROW	—	—	—
HANDLE, DOOR	—	—	—
RING ASSEMBLY	—	—	—
FRONT SHELL ASSEMBLY,	—	—	—
(SEE FIGURE 7-39)	—	—	—
HEATER TUMBLER ASSEMBLY,	—	—	—
(SEE FIGURE 7-40)	—	—	—
HOSE, AIR DUCT,	—	—	—
HOSE, FLEX	—	—	—
EXHAUST HOSE ADAPTER	—	—	—
ASSEMBLY	—	—	—
DUCT, HOSE,	—	—	—
REDUCER, PIPE,	—	—	—
ELBOW, AIR CONDITIONING	—	—	—
HEATING	—	—	—
PIN ASSEMBLY	—	—	—
PIN	—	—	—
CHAIN, SAFETY	—	—	—
HOOK, CHAIN,	—	—	—
THERMOMETER	—	—	—
DISCHARGE SPOUT ASSEMBLY	—	—	—
COUPLING, HALF	—	—	—
CONTROL, TEMPERATURE, DIAL	—	—	—
AND KNOB	—	—	—
CONNECTOR, ELBOW,	—	—	—
BOX CONNECTOR,	—	—	—
FAN ASSEMBLY, (SEE FIGURE 7-	—	—	—
41)	—	—	—
COVER	—	—	—
CONTROL PANEL ASSEMBLY,	—	—	—
(SEE FIGURE 7-42)	—	—	—

A-13

COMPONENTS	PASS	FAIL	REMARKS
TERMINAL, LUG,	_____	_____	_____
ELECTRODE ASSEMBLY	_____	_____	_____
ELECTRODE	_____	_____	_____
NOZZLE ASSEMBLY	_____	_____	_____
NOZZLE	_____	_____	_____
PIPE	_____	_____	_____
BASE, BURNER	_____	_____	_____
FRONT SHELL ASSEMBLY	_____	_____	_____
DOOR	_____	_____	_____
HINGE ASSEMBLY	_____	_____	_____
HINGE	_____	_____	_____
PIN, SPRING	_____	_____	_____
FRONT, SHELL	_____	_____	_____
HEATER TUMBLER ASSEMBLY	_____	_____	_____
SCREEN ASSEMBLY,	_____	_____	_____
PANEL, COVER	_____	_____	_____
HOOD ASSEMBLY	_____	_____	_____
HOOD	_____	_____	_____
PLATE	_____	_____	_____
COVER, FRONT	_____	_____	_____
COVER, REAR	_____	_____	_____
BURNER MOUNTING ASSEMBLY	_____	_____	_____
RETURN BOX NO 5 ASSEMBLY	_____	_____	_____
COVER, ASSEMBLY	_____	_____	_____
RETURN BOX NO 3 ASSEMBLY	_____	_____	_____
RETURN BOX NO 1 ASSEMBLY	_____	_____	_____
RETURN BOX NO 4 ASSEMBLY	_____	_____	_____
RETURN BOX NO 2 ASSEMBLY	_____	_____	_____
MOUNTING PLATE ASSEMBLY	_____	_____	_____
FAN ASSEMBLY	_____	_____	_____
FAN	_____	_____	_____
MOTOR, ALTERNATING,	_____	_____	_____
ARROW	_____	_____	_____
COVER, WELDMENT	_____	_____	_____
CONTROL PANEL ASSEMBLY	_____	_____	_____
STARTER, MANUAL	_____	_____	_____
PANEL ASSEMBLY	_____	_____	_____
CONTROL, FLAME	_____	_____	_____
PROGRAM TIME CARD,	_____	_____	_____
TERMINAL BOX, 12 SGL	_____	_____	_____
RELAY	_____	_____	_____
BASE, RELAY,	_____	_____	_____
SHIELD ASSEMBLY	_____	_____	_____
MOTOR, STARTER	_____	_____	_____
HEATER ELEMENT,	_____	_____	_____
TUMBLER SPEED REDUCER	_____	_____	_____
ASSEMBLY	_____	_____	_____
MOTOR, ALTERNATING	_____	_____	_____
MOUNTING BRACKET ASSEMBLY	_____	_____	_____
BASE ASSEMBLY	_____	_____	_____
TUMBLER ASSEMBLY	_____	_____	_____

COMPONENTS	PASS	FAIL	REMARKS
TIE ROD			
RIB, TUMBLER,			
SPIDER ASSEMBLY			
TUMBLER, CLOTHES DRYER			
EXHAUST TIE DOWN			
ASSEMBLY#1			
LEG			
STRAP, WEBBING,			
LOOP			
THREAD			
EXHAUST TIE DOWN			
ASSEMBLY#2			
LEG			
STRAP			
LOOP			
THREAD			
CONDUIT ASSEMBLY			
GROUND ROD, SECTION			
CONNECTOR, GROUND ROD			
WIRE, #8 STRANDED			
CONDUIT OUTLET			
COVER			
COVER, BLANK			
BODY, CONNECTOR			
COVER, CONNECTER			
PLUG, NYLON			
PLUG, COVER			
CONNECTOR			
BOX, TWO GANG			
BOX CONNECTOR,			
CLOTHES BIN ASSEMBLY			
HANDLE, SHORT			
HANDLE, LONG			
SIDE			
BASE			
COUPLING			
STAND, CLOTHES BIN			
CASTOR			
PLATFORM			
POWER CABLE ASSEMBLY			
BODY			
SHIELD, ELECTRICAL			
CABLE			

SOW-05-CSLE-09950A-2/1

13 MARCH 2002

COMPONENTS:

LIST OF DEFECTIVE PARTS

AND ASSEMBLIES

REMARKS:

Appendix B

LAUNDRY FACILITY BARE BASE

MAIN PLATFORM ASSEMBLY,

(SEE FIGURE 7 2)

STORAGE BIN ASSEMBLY,

(SEE FIGURE 7 3)

LAUNDRY WASHER ASSEMBLY,

(SEE FIGURE 7-4)

LAUNDRY WASHER ASSEMBLY,

(SEE FIGURE 7 7)

CLAMP ASSEMBLY,

(SEE FIGURE 7-13)

COUPLING

COUPLING HALF,

QUICK DISCONNECT,

CAM-LOCKING ALL ENDS

PLUG, SQ HD,

ELBOW, ST BRASS

BUSHING, BRASS,

COMPRESSOR UNIT,

RECIPROCATING,

(SEE FIGURE 7-14)

CONTROLLER AND

ELECTRICAL PANEL,

(SEE FIGURE 7-16)

WATER HEATER,

(SEE FIGURE 7-22)

HEATER FUEL LINE ASSEMBLY,

(SEE FIGURE 7-23)

HEATER TIEDOWN ASSEMBLY,

(SEE FIGURE 7-24)

LAUNDRY EXTRACTOR,

(SEE FIGURE 7-25)

TIE DOWN CLIP ASSEMBLY,

(SEE FIGURE 7-30)

WATER PUMP ASSEMBLY,

(SEE FIGURE 7-3 1)

HOSE CONNECT ASSEMBLY,

(SEE FIGURE 7 32)

PUMP TIEDOWN ASSEMBLY,

(SEE FIGURE 7 33)

DRYER ASSEMBLY,

(SEE FIGURE 7-34)

DRYER FUEL LINE ASSEMBLY,

(SEE FIGURE 7-23)

EXHAUST HOSE

TIEDOWN ASSEMBLY,

(SEE FIGURE 7-45)

EXHAUST HOSE

TIEDOWN ASSEMBLY,

(SEE, FIGURE 7-46)

CONDUIT ASSEMBLY,

(SEE FIGURE 7-47)

13 MARCH 2002

COMPONENTS:

LIST OF DEFECTIVE PARTS

AND ASSEMBLIES

REMARKS:

Appendix B

RAIL, SIDE, 84 IN LG
 CLOTHES BIN ASSEMBLY,
 (SEE, FIGURE 7-49)
 POWER CABLE ASSEMBLY,
 (SEE FIGURE, 7 49)
 SPACER
 COVER ASSEMBLY RED 1, 2, & 3
 MAIN PLATFORM ASSEMBLY
 PLATFORM, LEFT ASSEMBLY
 PLATFORM, FRAME ASSEMBLY
 DECK, LARGE TOP ASSEMBLY
 DECK, SMALL TOP ASSEMBLY
 DECK, LARGE BOTTOM ASSEMBLY
 DECK, SMALL BOTTOM ASSEMBLY
 RAIL
 RAIL, SIDE
 SLEEVE
 STRAP, RETAINING,
 PLATFORM, RIGHT ASSEMBLY
 JOINING PANEL ASSEMBLY
 STORAGE BIN ASSEMBLY
 BIN, LARGE
 PLATFORM
 BIN, SMALL
 COVER ASSEMBLY
 FASTENER, LINK LOCK
 TRAY
 LAUNDRY WASHER
 WASHER ASSEMBLY,
 (SEE FIGURE 7-5)
 PLATE, TANK MOUNTING
 ELBOW, PIPE,
 TEE, PIPE, STL,
 COCK, DRAIN,
 WASHER ASSEMBLY, OPEN END
 COVER, BASE SIDE LEFT
 COVER, BASE FRONT
 COVER, BASE SIDE RIGHT
 SUPPLY INJECTOR ASSEMBLY
 SHELL ASSEMBLY
 SHELL FRONT ASSEMBLY
 SHELL, EXTRUSION
 RING, SHELL
 PLATE, MOUNTING
 MICROSWITCH
 CAM, CONTROL
 HANDLE ASSEMBLY
 DOOR, ASSEMBLY
 BRACKET, HINGE
 CYLINDER ASSEMBLY
 HOUSING, SHAFT SEAL
 GASKET, SHAFTSEAL

13 MARCH 2002

COMPONENTS:

LIST OF DEFECTIVE PARTS
AND ASSEMBLIES

Appendix B

REMARKS:

SEAL, PLAIN, STL,
COVER, SHAFT RETAINER
SPACER, SHAFT RETAINER
KEY, MACHINE, STL
SPIDER,
GEAR ASSEMBLY,
SPEED DECREASER
MOTOR, ALTERNATING
MOUNT, MOTOR
BRACKET, MOTOR MOUNT, LEFT
BRACKET, MOTOR MOUNT, RIGHT
BELT GUARD ASSEMBLY
BRACKET, BELT UPPER
BELT, V, RBR,
BRACKET, BELT, LOWER LEFT
PULLEY, GROOVE,
BUSHING, SLEEVE
V-PULLEY
BUSHING, SLEEVE
COVER, SYPHON
BREAKER
PIPE, ELBOW
WATER LEVEL FLOAT,
CHAMBER ASSEMBLY,
(SEE FIGURE 7-6)
SOAP CHUTE
COVER, SOAP CHUTE
HINGE, SOAP CHUTE
ROD, SOAP CHUTE
PIPE, METALLIC
HOSE, NONMETALLIC,
PIPE, WATER INLET
VALVE, ANGLE,
WATER LEVEL FLOAT
CHAMBER ASSEMBLY
SWITCH, LIQUID LEVEL
TUBING, GLASS,
CLAMP, LOOP
BRACKET, LEVEL CONTROL
BRACKET, TOP FLOAT
CHAMBER
BRACKET, BOTTOM
FLOAT CHAMBER
FLOAT ASSEMBLY,
LIQUID LEVEL
FLOAT
ROD, FLOAT,
SPEED NUT
LAUNDRY WASHER ASSEMBLY
FRAME ASSEMBLY
DOOR ASSEMBLY, (SEE FIGURE 7-
8)

COMPONENTS:

REMARKS:

Appendix B

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There is no text or other markings on the paper.

13 MARCH 2002

COMPONENTS:

LIST OF DEFECTIVE PARTS
AND ASSEMBLIES

Appendix B

REMARKS:

DOOR LOCK ASSEMBLY

DOOR LOCK COVER AND SWITCH

COVER, DOOR LOCK

SWITCH, PUSH

BOOT, DUST AND MOISTURE SEAL

BRACKET, MOUNTING

BUSHING, ELECTRICAL

CONDUCTOR,

SOLENOID,

SWITCH,

PLATE, DOOR LOCK

SPRING, DOOR LOCK

BAR, DOOR LOCK

SPRING, DOOR LATCH

WATER INLET ASSEMBLY

LEVER, MANUAL CONTROL

CLEVIS, ROD END,

CYLINDER ASSEMBLY,

ROD, ADJUSTING STUD

BRACKET, MOUNTING

COUPLER, FEMALE

COUPLING HALF, QUICK

DISCONNECT,

ELBOW, PIPE,

NIPPLE, PIPE,

PIPE, METALLIC,

ELBOW, PIPE TO HOSE,

ELBOW, PIPE,

BUSHING, PIPE

TEE, PIPE

VALVE, BALL,

NIPPLE, PIPE,

DISPENSER ASSEMBLY

DISPENSER

COVER

HOSE, SUPPLY 1

SUPPLY HOSE, AIR

HOSE, SUPPLY 2

HOSE, SUPPLY 3

HOSE, SUPPLY 4

FITTING, HOSE

COUPLING, PIPE,

HOSE, SUPPLY INLET

ADAPTER, STRAIGHT

VALVE, SOLENOID,

MANIFOLD, SUPPLY

BRACKET, MANIFOLD

MOUNTING

DRAIN VALVE ASSEMBLY

PLATE, TOP

BELLOWS, RUBBER,

ADAPTER, STRAIGHT,

13 MARCH 2002

COMPONENTS:

LIST OF DEFECTIVE PARTS

AND ASSEMBLIES

Appendix B

REMARKS:

PLATE, MOUNTING
 BRACKET
 HOSE, NONMETALLIC,
 PINCH TUBE
 CLAMP ASSEMBLY
 ANGLE
 ROD, THREADED, SHORT
 RING, HANGER
 AIR COMPRESSOR ASSEMBLY
 GRILLE, METAL
 HANDLE, DOOR, L STYLE
 KIT, SWITCH, (SEE FIGURE 7-15)
 HOUSING, AIR COMPRESSOR
 CYLINDER, HEAD ASSEMBLY,
 RIGHT HAND
 CYLINDER HEAD ASSEMBLY,
 LEFT HAND
 MOTOR, ALTERNATING
 CABLE ASSEMBLY,
 PRESSURE SWITCH ASSEMBLY
 SWITCH, PRESSURE
 PLUG, BUTTON
 WIRE ASSEMBLY, BLK
 WIRE ASSEMBLY, WHT
 CONTROLLER AND ELECTRICAL
 PANELSUPPORT FRAME
 ASSEMBLY
 FACE PLATE, LAUNDRY,
 COVER, CONTROLLER
 CONTROLLER ASSEMBLY
 HEAD ASSEMBLY,
 CONTROL BOX, (SEE FIGURE 7-17)
 CONTROL BOX ASSEMBLY,
 (SEE FIGURE 7-18)
 CONTROL CHASIS
 ASSEMBLY, LAUNDRY,
 (SEE FIGURE 7-19)
 HOSE, LOW PRESSURE
 ADAPTER, STRAIGHT
 SLEEVE
 FIRE EXTINGUISHER
 PLATE, MOUNTING
 STAND, CONTROLLER SUPPORT
 LOAD CENTER
 ENCLOSURE
 BRACKET, INTERIOR MOUNT
 KIT, INTERIOR TRIM
 CAP, END SEAL
 MAIN BREAKER, 30 AMP
 CIRCUIT BREAKER, 20 AMP
 BOX, 3 GANG
 GASKET, SYNTH-RBR,

13 MARCH 2002

COMPONENTS:

LIST OF DEFECTIVE PARTS

AND ASSEMBLIES

Appendix B

REMARKS:

CONNECTOR, RECEPTACLE
 OUTLET
 COVER, CONDUIT
 COVER, LIFT
 SWITCH, MOTOR STARTING
HEAD ASSEMBLY
 WINDOW, OBSERVATION,
 LATCH, SPECIAL
 LAMP, 28V
 SOCKET, LAMP
 NAME PLATE
 WARNING
 NAME PLATE,
 TUBING,
 TYRAP,
 BRACKET, RECEPTACLE
 RECEPTACLE
 ANGLE, CENTER
 DOOR ASSEMBLY, PLASTIC
 WET PART, LAUNDRY
 PARTITION, SWITCH
 SKIRT, TIMING, LAUNDRY
REAR ASSEMBLY
 BACK
 POWER SUPPLY
 VALVE, SOLENOID,
 STRAINER, SEDIMENT,
 NIPPLE, PIPE,
 ANGLE
 PLUG, PIPE
 BLOCK, MANIFOLD,
CONTROL CHASIS ASSEMBLY
 CONTROL PANEL ASSEMBLY,
 (SEE FIGURE 7-20)
 FUSE, CARTRIDGE,
 FUSEHOLDER,
 VALVE, SOLENOID,
 VALVE, AIR CONTROL, 3 WAY
 RELAY, 3PDT, 10 AMP
 SWITCH, PRESSURE
 RELAY,
 TIMING MOVEMENT,
 MECHANICAL,
 (SEE FIGURE 7-21)
CONTROL PANEL ASSEMBLY
 PANEL, CONTROL
 TIMER, SEQUENTIAL
 SWITCH, TOGGLE,
 COVER, SWITCH
REVERSING TIMER ASSEMBLY
 SHAFT, SHOULDERED,
 SWITCH, SENSITIVE,

COMPONENTS:

LIST OF DEFECTIVE PARTS AND ASSEMBLIES

Appendix B

REMARKS:

ADAPTER, SWITCH
CAM, CONTROL
SETSCREW,
BRACKET, TIMER
**LAUNDRY EXTRACTOR
ASSEMBLY**
EXTRACTOR, BOCK MOISTRITE
AND SPEEDRY
MOTOR ASSEMBLY,
(SEE FIGURE 7-26)
MOTOR ASSEMBLY,
(SEE FIGURE 7-27)
SHEAVE, PULLEY
V-BELT
LID
FRAME, LID HINCE
BASKET BALL
LID GASKET
CURB ASSEMBLY
WASHER, LEAD
RUBBER WASHER
HOSE,
BASKET ASSEMBLY
POST, CENTER
SEAL,
CENTER UNIT ASSEMBLY,
(SEE FIGURE 7-28)
HUB, BRAKE
BACK PANEL ASSEMBLY,
(SEE FIGURE 7,29)
BASE ASSEMBLY
TRUNNION FRAME, ASSEMBLY
COUPLING HALF,
MOTOR ASSEMBLY #1
MOTOR, 3 HP
SWITCH,
MOUNT, SWITCH
COUPLING
HUB, BODY,
PLATE, MOTOR MOUNT
MOTOR ASSEMBLY #2
MOTOR
HUB, PULLEY
PLATE, MOTOR MOUNT
CENTER UNIT ASSEMBLY
PIN, STUD
ARM, BRAKE
ARM, OPERATING
BRACKET
SPRING, HELICAL, EXTENSION
BRAKE SHOE,
COVER, TOP END

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There is no text or other markings on the paper.

13 MARCH 2002

COMPONENTS:

LIST OF DEFECTIVE PARTS

AND ASSEMBLIES

REMARKS:

SHIELD, SOLENOID
ROD, SOLENOID
SOLENOID, BRAKE
HUB
BALL, BASKET
INSERT, NYLON
PACKING,
CAP, BUMPER
BUMPER RUBBERS
CAP, TRUNNION
RUBBER, TRUNNION
HUB, PULLEY
SHEAVES, PULLEY
BACK PANEL ASSEMBLY
BUTTON, START
SWITCH, PUSH-PULL,
BUTTON, RED
LIGHT, INDICATOR
MICROSWITCH
SOLENOID,
RELAY, ELECTRO MAGNETIC
TIMER,
FUSE HOLDER
FUSE, CARTRIDGE,
TERMINAL BOARD
COVER
PLATE, BOTTOM
BACK AND SIDES, CONTROL
PANEL
PLATE, MOUNT
PLATE, TOP
TIE DOWN CLIP ASSEMBLY
BAR, TIE DOWN CLIP
LEG, TIE DOWN CLIP
PLATFORMS
WATER PUMP ASSEMBLY
WATER PUMP ASSEMBLY
FRAME, AL-ALY
SWITCH BOX ASSEMBLY
COVERS
COVER, BOX, FRONT
PUMP UNIT
BRACKET
MOTOR, ALTERNATING
CAP,
COUPLING HALF,
NIPPLE, PIPE
HOSE CONNECTION ASSEMBLY
SUCTION STRAINER ASSEMBLY
COUPLING, QUICK DISCONNECT
SUCTION HOSE ASSEMBLY
COUPLING, HALF

13 MARCH 2002

COMPONENTS:

LIST OF DEFECTIVE PARTS

AND ASSEMBLIES

REMARKS:

Appendix B

HEATER INTAKE HOSE ASSEMBLY
WASHER, INTAKE HOSE
ASSEMBLY
HOSES, WATER,
CLOTHES BIN DISCHARGE HOSE
EXTRACTOR DISCHARGE HOSE
ASSEMBLY
PUMP TIE DOWN ASSEMBLY
CATCH, FIXED ASSEMBLY
CATCH, ADJUSTABLE
PLATFORM ASSEMBLY
DRYER ASSEMBLY
BLOWER ASSEMBLY,
(SEE FIGURE 7-35)
HOSE ASSEMBLIES
BURNER TUMBLER ASSEMBLY,
(SEE FIGURE 7-36)
SWITCHES, SENSITIVE
COVER
LIGHT, INDICATOR,
ALARM, BUZZER
BUZZER,
DOOR ASSEMBLY
CHAIN, WELDLESS
TIMER, SEQUENTIAL
PLATE, INDENT
LABEL, CAUTION
LABEL, WARNING
ARROW
HANDLE, DOOR
RING ASSEMBLY
FRONT SHELL ASSEMBLY,
(SEE FIGURE 7-39)
HEATER TUMBLER ASSEMBLY,
(SEE FIGURE 7-40)
HOSE, AIR DUCT,
HOSE, FLEX
EXHAUST HOSE ADAPTER
ASSEMBLY
DUCT, HOSE,
REDUCER, PIPE,
ELBOW, AIR CONDITIONING
HEATING
PIN ASSEMBLY
PIN
CHAIN, SAFETY
HOOK, CHAIN,
THERMOMETER
DISCHARGE SPOUT ASSEMBLY
COUPLING, HALF
CONTROL, TEMPERA TURE, DIAL
AND KNOB

13 MARCH 2002

COMPONENTS:

LIST OF DEFECTIVE PARTS
AND ASSEMBLIES

Appendix B

REMARKS:

CONNECTOR, ELBOW,
BOX CONNECTOR,
FAN ASSEMBLY, (SEE FIGURE 7-41)
COVER
CONTROL PANEL ASSEMBLY,
(SEE FIGURE 7-42)
TUMBLER SPEED REDUCER
ASSEMBLY,
(SEE FIGURE 7-43)
ROD, THREADED
CUP, GREASE,
CUP OIL,
PLATES, RETAINING,
GUARD
CHAIN, STL, 65 LINKS
WIRE, SAFETY
TUMBLER ASSEMBLY,
(SEE, FIGURE 7-44)
SHELL ASSEMBLY
TUMBLER BASE ASSEMBLY
PANEL, SIDE
INSULATOR, PLATE,
STRIP
BLOWER ASSEMBLY
GUAGE, PRESSURE
COCK, DRAIN
TEE
NIPPLE
PUMP, FUEL
SHUTTER ASSEMBLY,
HOUSING
HOUSING, BLOWER
WHEEL, BLOWER
MOUNT, BLOWER
KEY
MOTOR, ALTERNATING
BURNER TUMBLER ASSEMBLY
CAP FITTING
GASKET, PEEP SIGHT,
GLASS, PEEP HOLE
NIPPLE
COVER
CABLE AND TERMINAL
ASSEMBLY,
(SEE FIGURE 7-37)
ELECTRODE ASSEMBLY,
(SEE FIGURE 7-38)
BRACKET, TRANSFORMER
TRANSFORMER
BOX, JUNCTION
COVER
BOX CONNECTORS,

COMPONENTS:

Appendix B

Blank lined paper.

COMPONENTS:

LIST OF DEFECTIVE PARTS AND ASSEMBLIES

Appendix B

REMARKS:

MOTOR, ALTERNATING
 MOUNTING BRACKET ASSEMBLY
 BASE ASSEMBLY
 TUMBLER ASSEMBLY
 TIE ROD
 RIB, TUMBLER,
 SPIDER ASSEMBLY
 TUMBLER, CLOTHES DRYER
 EXHAUST TIE DOWN
 ASSEMBLY#1
 LEG
 STRAP, WEBBING,
 LOOP
 THREAD
 EXHAUST TIE DOWN
 ASSEMBLY#2
 LEG
 STRAP
 LOOP
 THREAD
 CONDUIT ASSEMBLY
 GROUND ROD, SECTION
 CONNECTOR, GROUND ROD
 WIRE, #8 STRANDED
 CONDUIT OUTLET
 COVER
 COVER, BLANK
 BODY, CONNECTOR
 COVER, CONNECTER
 PLUG, NYLON
 PLUG, COVER
 CONNECTOR
 BOX, TWO GANG
 BOX CONNECTOR,
 CLOTHES BIN ASSEMBLY
 HANDLE, SHORT
 HANDLE, LONG
 SIDE
 BASE
 COUPLING
 STAND, CLOTHES BIN
 CASTOR
 PLATFORM
 POWER CABLE ASSEMBLY
 BODY
 SHIELD, ELECTRICAL
 CABLE

Blank lined paper for writing.

LIST OF REPAIR PARTS AND
ASSEMBLIES REQUIRED FOR
REPAIRS

COMPONENTS:

REMARKS:

LAUNDRY FACILITY BARE BASE
MAIN PLATFORM ASSEMBLY,
(SEE FIGURE 7 2)
STORAGE BIN ASSEMBLY,
(SEE FIGURE 7 3)
LAUNDRY WASHER ASSEMBLY,
(SEE FIGURE 7-4)
LAUNDRY WASHER ASSEMBLY,
(SEE FIGURE 7 7)
CLAMP ASSEMBLY,
(SEE FIGURE 7-13)
COUPLING
COUPLING HALF,
QUICK DISCONNECT,
CAM-LOCKING ALL ENDS
PLUG, SQ HD,
ELBOW, ST BRASS
BUSHING, BRASS,
COMPRESSOR UNIT,
RECIPROCATING,
(SEE FIGURE 7-14)
CONTROLLER AND
ELECTRICAL PANEL,
(SEE FIGURE 7-16)
WATER HEATER,
(SEE FIGURE 7-22)
HEATER FUEL LINE ASSEMBLY,
(SEE FIGURE 7-23)
HEATER TIEDOWN ASSEMBLY,
(SEE FIGURE 7-24)
LAUNDRY EXTRACTOR,
(SEE FIGURE 7-25)
TIE DOWN CLIP ASSEMBLY,
(SEE FIGURE 7-30)
WATER PUMP ASSEMBLY,
(SEE FIGURE 7-3 1)
HOSE CONNECT ASSEMBLY,
(SEE FIGURE 7 32)
PUMP TIEDOWN ASSEMBLY,
(SEE FIGURE 7 33)
DRYER ASSEMBLY,
(SEE FIGURE 7-34)
DRYER FUEL LINE ASSEMBLY,
(SEE FIGURE 7-23)
EXHAUST HOSE
TIEDOWN ASSEMBLY,
(SEE FIGURE 7-45)
EXHAUST HOSE
TIEDOWN ASSEMBLY,
(SEE, FIGURE 7-46)
CONDUIT ASSEMBLY,

Appendix C

REMARKS:

[illegible]

Appendix C

REMARKS:

[illegible]

REMARKS:

[illegible]

**LIST OF REPAIR PARTS AND
ASSEMBLIES REQUIRED FOR
REPAIRS**

COMPONENTS:

REMARKS:

FRAME, DOOR
DRAW BAND, DOOR
GASKET, DRAW BAND
GASKET, DOOR
DOOR LOCK ASSEMBLY
DOOR LOCK COVER AND SWITCH
COVER, DOOR LOCK
SWITCH, PUSH
BOOT, DUST AND MOISTURE SEAL
BRACKET, MOUNTING
BUSHING, ELECTRICAL
CONDUCTOR,
SOLENOID,
SWITCH,
PLATE, DOOR LOCK
SPRING, DOOR LOCK
BAR, DOOR LOCK
SPRING, DOOR LATCH
WATER INLET ASSEMBLY
LEVER, MANUAL CONTROL
CLEVIS, ROD END,
CYLINDER ASSEMBLY,
ROD, ADJUSTING STUD
BRACKET, MOUNTING
COUPLER, FEMALE
COUPLING HALF, QUICK
DISCONNECT,
ELBOW, PIPE,
NIPPLE, PIPE,
PIPE, METALLIC,
ELBOW, PIPE TO HOSE,
ELBOW, PIPE,
BUSHING, PIPE
TEE, PIPE
VALVE, BALL,
NIPPLE, PIPE,
DISPENSER ASSEMBLY
DISPENSER
COVER
HOSE, SUPPLY 1
SUPPLY HOSE, AIR
HOSE, SUPPLY 2
HOSE, SUPPLY 3
HOSE, SUPPLY 4
FITTING, HOSE
COUPLING, PIPE,
HOSE, SUPPLY INLET
ADAPTER, STRAIGHT
VALVE, SOLENOID,
MANIFOLD, SUPPLY
BRACKET, MANIFOLD

LIST OF REPAIR PARTS AND
ASSEMBLIES REQUIRED FOR
REPAIRS

COMPONENTS:

REMARKS:

MOUNTING
DRAIN VALVE ASSEMBLY
PLATE, TOP
BELLOWS, RUBBER,
ADAPTER, STRAIGHT,
PLATE, MOUNTING
BRACKET
HOSE, NONMETALLIC,
PINCH TUBE
CLAMP ASSEMBLY
ANGLE
ROD, THREADED, SHORT
RING, HANGER
AIR COMPRESSOR ASSEMBLY
GRILLE, METAL
HANDLE, DOOR, L STYLE
KIT, SWITCH, (SEE FIGURE 7-15)
HOUSING, AIR COMPRESSOR
CYLINDER, HEAD ASSEMBLY,
RIGHT HAND
CYLINDER HEAD ASSEMBLY,
LEFT HAND
MOTOR, ALTERNATING
CABLE ASSEMBLY,
PRESSURE SWITCH ASSEMBLY
SWITCH, PRESSURE
PLUG, BUTTON
WIRE ASSEMBLY, BLK
WIRE ASSEMBLY, WHT
CONTROLLER AND ELECTRICAL
PANELSUPPORT FRAME
ASSEMBLY
FACE PLATE, LAUNDRY,
COVER, CONTROLLER
CONTROLLER ASSEMBLY
HEAD ASSEMBLY,
CONTROL BOX, (SEE FIGURE 7-17)
CONTROL BOX ASSEMBLY,
(SEE FIGURE 7-18)
CONTROL CHASIS
ASSEMBLY, LAUNDRY,
(SEE FIGURE 7-19)
HOSE, LOW PRESSURE
ADAPTER, STRAIGHT
SLEEVE
FIRE EXTINGUISHER
PLATE, MOUNTING
STAND, CONTROLLER SUPPORT
LOAD CENTER
ENCLOSURE
BRACKET, INTERIOR MOUNT

**LIST OF REPAIR PARTS AND
ASSEMBLIES REQUIRED FOR
REPAIRS**

COMPONENTS:

REMARKS:

KIT, INTERIOR TRIM
CAP, END SEAL
MAIN BREAKER, 30 AMP
CIRCUIT BREAKER, 20 AMP
BOX, 3 GANG
GASKET, SYNTH-RBR,
CONNECTOR, RECEPTACLE
OUTLET
COVER, CONDUIT
COVER, LIFT
SWITCH, MOTOR STARTING
HEAD ASSEMBLY
WINDOW, OBSERVATION,
LATCH, SPECIAL
LAMP, 28V
SOCKET, LAMP
NAME PLATE
WARNING
NAME PLATE,
TUBING,
TYRAP,
BRACKET, RECEPTACLE
RECEPTACLE
ANGLE, CENTER
DOOR ASSEMBLY, PLASTIC
WET PART, LAUNDRY
PARTITION, SWITCH
SKIRT, TIMING, LAUNDRY
REAR ASSEMBLY
BACK
POWER SUPPLY
VALVE, SOLENOID,
STRAINER, SEDIMENT,
NIPPLE, PIPE,
ANGLE
PLUG, PIPE
BLOCK, MANIFOLD,
CONTROL CHASIS ASSEMBLY
CONTROL PANEL ASSEMBLY,
(SEE FIGURE 7-20)
FUSE, CARTRIDGE,
FUSEHOLDER,
VALVE, SOLENOID,
VALVE, AIR CONTROL, 3 WAY
RELAY, 3PDT, 10 AMP
SWITCH, PRESSURE
RELAY,
TIMING MOVEMENT,
MECHANICAL,
(SEE FIGURE 7-21)
CONTROL PANEL ASSEMBLY

Appendix C

REMARKS:

[illegible]

**LIST OF REPAIR PARTS AND
ASSEMBLIES REQUIRED FOR
REPAIRS**

COMPONENTS:

REMARKS:

CENTER UNIT ASSEMBLY

PIN, STUD
ARM, BRAKE
ARM, OPERATING
BRACKET
SPRING, HELICAL, EXTENSION
BRAKE SHOE,
COVER, TOP END
SHIELD, SOLENOID
ROD, SOLENOID
SOLENOID, BRAKE
HUB
BALL, BASKET
INSERT, NYLON
PACKING,
CAP, BUMPER
BUMPER RUBBERS
CAP, TRUNNION
RUBBER, TRUNNION
HUB, PULLEY
SHEAVES, PULLEY

BACK PANEL ASSEMBLY

BUTTON, START
SWITCH, PUSH-PULL,
BUTTON, RED
LIGHT, INDICATOR
MICROSWITCH
SOLENOID,
RELAY, ELECTRO MAGNETIC
TIMER,
FUSE HOLDER
FUSE, CARTRIDGE,
TERMINAL BOARD
COVER
PLATE, BOTTOM
BACK AND SIDES, CONTROL
PANEL
PLATE, MOUNT
PLATE, TOP

TIE DOWN CLIP ASSEMBLY

BAR, TIE DOWN CLIP
LEG, TIE DOWN CLIP
PLATFORMS

WATER PUMP ASSEMBLY

WATER PUMP ASSEMBLY
FRAME, AL-ALY
SWITCH BOX ASSEMBLY
COVERS

COVER, BOX, FRONT
PUMP UNIT
BRACKET

REMARKS:

This image shows a single page of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There is no text or other markings on the paper.

Appendix C

REMARKS:

HEATING
 PIN ASSEMBLY
 PIN
 CHAIN, SAFETY
 HOOK, CHAIN,
 THERMOMETER
 DISCHARGE SPOUT ASSEMBLY
 COUPLING, HALF
 CONTROL, TEMPERA TURE, DIAL
 AND KNOB
 CONNECTOR, ELBOW,
 BOX CONNECTOR,
 FAN ASSEMBLY, (SEE FIGURE 7-41)
 COVER
 CONTROL PANEL ASSEM BLY,
 (SEE FIGURE 7-42)
 TUMBLER SPEED REDUCER
 ASSEMBLY,
 (SEE FIGURE 7-43)
 ROD, THREADED
 CUP, GREASE,
 CUP OIL,
 PLATES, RETAINING,
 GUARD
 CHAIN, STL, 65 LINKS
 WIRE, SAFETY
 TUMBLER ASSEMBLY,
 (SEE, FIGURE 7-44)
 SHELL ASSEMBLY
 TUMBLER BASE ASSEMBLY
 PANEL, SIDE
 INSULATOR, PLATE,
 STRIP
BLOWER ASSEMBLY
 GUAGE, PRESSURE
 COCK, DRAIN
 TEE
 NIPPLE
 PUMP, FUEL
 SHUTTER ASSEMBLY,
 HOUSING
 HOUSING, BLOWER
 WHEEL, BLOWER
 MOUNT, BLOWER
 KEY
 MOTOR, ALTERNATING
BURNER TUMBLER ASSEMBLY
 CAP FITTING
 GASKET, PEEP SIGHT,
 GLASS, PEEP HOLE
 NIPPLE

Appendix C

REMARKS:

COVER
CABLE AND TERMINAL
ASSEMBLY,
(SEE FIGURE 7-37)
ELECTRODE ASSEMBLY,
(SEE FIGURE 7-38)
BRACKET, TRANSFORMER
TRANSFORMER
BOX, JUNCTION
COVER
BOX CONNECTORS,
CONNECTOR, STRAIGHT
AIR PLENUM
CABLE AND TERMINAL
ASSEMBLY
CABLE
TERMINAL, LUG,
ELECTRODE ASSEMBLY
ELECTRODE
NOZZLE ASSEMBLY
NOZZLE
PIPE
BASE, BURNER
FRONT SHELL ASSEMBLY
DOOR
HINGE ASSEMBLY
HINGE
PIN, SPRING
FRONT, SHELL
HEATER TUMBLER ASSEMBLY
SCREEN ASSEMBLY,
PANEL, COVER
HOOD ASSEMBLY
HOOD
PLATE
COVER, FRONT
COVER, REAR
BURNER MOUNTING ASSEMBLY
RETURN BOX NO 5 ASSEMBLY
COVER, ASSEMBLY
RETURN BOX NO 3 ASSEMBLY
RETURN BOX NO 1 ASSEMBLY
RETURN BOX NO 4 ASSEMBLY
RETURN BOX NO 2 ASSEMBLY
MOUNTING PLATE ASSEMBLY
FAN ASSEMBLY
FAN
MOTOR, ALTERNATING,
ARROW
COVER, WELDMENT
CONTROL PANEL ASSEMBLY

[illegible]

Appendix C

REMARKS:

[illegible]

SOW-05-CSLE-09950A-2/1
13 MARCH 2002

**LIST OF REPAIR PARTS AND
ASSEMBLIES REQUIRED FOR
REPAIRS**

Appendix C

COMPONENTS:

REMARKS:

COUPLING
STAND, CLOTHES BIN
CASTOR
PLATFORM
POWER CABLE ASSEMBLY
BODY
SHIELD, ELECTRICAL
CABLE
